



# **RS-422/485 Serial Device Server**

**User's Manual**

# Table of contents

<b>Table of contents</b> .....	2	- Sharing a local serial port on PC.....	10
<b>Copyright statement</b> .....	3	- Connecting to a shared serial port from the serial device server.....	12
<b>Disclaimer</b> .....	3	- Creating UDP Connecting .	13
<b>Safety instructions</b> .....	3	<b>Serial to Ethernet Toolkit ...</b>	<b>15</b>
<b>Introduction</b> .....	4	- Search a serial device .....	15
<b>Features</b> .....	4	<b>Web console</b> .....	<b>16</b>
<b>System requirement</b> .....	4	- Network settings.....	17
<b>Package contents</b> .....	5	- Serial Port.....	19
<b>Specifications</b> .....	5	- Advance.....	20
<b>Product overview</b> .....	6	- Security .....	22
- 1-Port RS-422/485 serial device server .....	6	<b>Telnet console configuration</b> .....	<b>23</b>
- 2-Port RS-422/485 serial device server .....	7	.....	<b>23</b>
- Driver installation.....	8	Commands reference .....	24
- Uninstall the software .....	9	<b>Connection diagram</b> .....	<b>27</b>
- Uninstall the Serial to Ethernet Connector.....	9	<b>Regulatory compliance</b> .....	<b>28</b>
- Uninstall the Serial to Ethernet Toolkit .....	9	FCC conditions .....	28
<b>Using SEC (Serial-to-Ethernet Connector)</b> .....	<b>10</b>	CE.....	28
		WEEE Information .....	28

Before attempting to connect, operate or adjust this product, please save and read the User's Manual completely. The style of the product shown in this User's Manual may be different from the actual unit due to various models.

## **Copyright statement**

No part of this publication may be reproduced in any form by any means without the prior written permission. Other trademarks or brand names mentioned herein are trademarks or registered trademarks of their respective companies.

## **Disclaimer**

Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage.

## **Safety instructions**

Always read the safety instructions carefully:

- Keep this User's Manual for future reference
- Keep this equipment away from humidity
- If any of the following situation arises, get the equipment checked by a service technician:
  - The equipment has been exposed to moisture.
  - The equipment has been dropped and damaged.
  - The equipment has obvious sign of breakage.
    - The equipment has not been working well or cannot get it to work according to the User's Manual.

# Introduction

The Ethernet Serial Device Server connects remote RS-422/485 devices via Ethernet as an operation center between RS-422/485 serial devices and the Internet. Once your computer connects to the Ethernet Serial Device Server via Ethernet, the virtual ports can provide communication to devices without altering any applications on your computer. It not only provides fine remote communication but remove the restriction for distance. This server is quite suitable for applying remote data accessing, security monitoring, and manufacture automation.

## Features

- Compact size design, easy installation
- Versatile operation mode support, include TCP Server, TCP Client and UDP
- 10/100 Mbps Ethernet port for LAN
- Support 2/4 wires RS-422/485, Auto RS-485 flow control
- 15KVDC ESD immunity to serial interface
- Support 5VDC or 9~36 DC wide range power input
- 3KV optical couple isolation
- Wall mount support

## System requirement

- IBM Compatible computer
- Windows 2000<sup>®</sup>, Windows XP<sup>®</sup> 32/64 bit, Windows Vista<sup>®</sup> 32/64 bit, Windows 7<sup>®</sup> 32/64 bit
- 64 MB RAM or higher
- Pentium<sup>®</sup> 233 MHz or higher

# Package contents

- Serial Device Server x1
- DC Power Adapter x1
- 5-pin terminal block x1 (1-port RS422/485 model)
- 5-pin terminal block x2 (2-port RS422/485 model)
- 3-pin terminal block x1
- CD (Driver and User's Manual) x1


# Specifications

Item	Description
<b>Ports</b>	1xRS-422/485
	2xRS-422/485 (2-port RS422/485 model)
<b>Connector</b>	5-pin terminal block
<b>ESD Protection</b>	15 KV ESD, 3KV isolation
<b>Serial Communication Speed</b>	110 bps~230.4 KBps
<b>Interface</b>	10/100 Base T Ethernet
<b>Interface Connector</b>	RJ-45
<b>Power Requirement</b>	5V3A DC, 9~36VDC
<b>Operating Temperature</b>	0°C to 55°C
<b>Operating Humidity</b>	5 to 95% RH
<b>Dimension (LxWxH)</b>	100 x 60 x 29 mm
<b>Regulatory Approvals</b>	FCC/CE

Specification is subject to change without further notice.


# Product overview

## 1-Port RS-422/485 serial device server




**1** Power LED


**2** Status LED



**3** Wall Mount Hole



**4** Serial Port  
(RS422/485)




**5** DC Power jack

**6** DC Power (9~36VDC)


**7** Network

## 2-Port RS-422/485 serial device server




**1** Power LED


**2** Status LED



**3** Wall Mount Hole



**4** Serial Port  
(RS422/485)




**5** DC Power jack

**6** DC Power (9~36VDC)

**7** Network



# Driver installation

1. Double click **SDS\_Setup** in order to start installation process.



**Note:** This driver combines the utilities of **Serial to Ethernet Connector** and **Serial to Ethernet Toolkit**. Both utilities will be installed to the computer after running the installation.

2. Follow the on-screen instructions to complete the installation.

Once the installation has been completed, two shortcuts (  and  ) will appear on the desktop. To launch the utility, double-click the shortcut which created on the desktop. Alternatively, navigate the **Start** menu and locate the launcher in **Programs** submenu.


**Note:** Please install the utility before connecting the serial server to a computer.



# Uninstall the software


## Uninstall the Serial to Ethernet Connector

To uninstall the **Uninstall Serial to Ethernet Connector**, click on **Uninstall Serial to Ethernet Connector** under **Ethernet Software** item in **Programs** submenu, and then follow the on-screen instructions.



## Uninstall the Serial to Ethernet Toolkit

1. To uninstall the **Serial to Ethernet Toolkit**, click **Control Panel** in **Programs** submenu.
2. Click **Uninstall a program** under **Program** > right click on **Select Serial Device Server** to bring up **Uninstall**.




# Using SEC (Serial-to-Ethernet Connector)

Serial to Ethernet Connector is an advanced software-based solution that allows you to share serial port devices over network and can be accessed from anywhere in the world (via Internet or LAN) as if it is attached directly to the remote PC. When the attached serial port device sends communication data, it is actually transmitted over TCP/IP network and back from the network to your serial device. To start the utility, click **Serial to Ethernet Connector**.

## Sharing a local serial port on PC

1. In **Create connection** tab choose the required connection type: Share serial port for incoming connections (Server). Also specify the name to identify this connection, for instance, COM1 [Server]



2. Select local serial port to be shared. For example, COM1



**Note:** A serial port name must not contain spaces inside.

3. Tick **Create as virtual serial port** checkbox to use a virtual serial port instead of a real one. The advantage of virtual serial ports technology is that you are not limited to the number of physical serial ports in a system, and thus you can free existing serial ports for other applications.

**Note:** A virtual serial port can have the same name as the existing physical COM port. But in this case it will be accessed instead of physical one.

4. Tick **Strict baud rate emulation** checkbox if you want to enable baud rate emulation, which permits virtual ports to work with the same speed as real ones.
5. Specify TCP port, which will be used in connection. Make sure this port is not blocked by firewall and is not used by other servers in your system (DNS, SMTP, IIS, etc.).

Select port type you want to create

Select Serial Port: COM1

**port for sharing**

Remote IP/Host name: localhost : 5000

TCP port

Create as virtual serial port

Strict baudrate emulation

6. Click **Create connection** button.

COM1 [Server] Create connection

Select connection type you want to create

Share serial port for incoming connections (Server)


Connect serial port to remote host (Client)

Share serial port using UDP


7. Now the shared serial port can be accessed from the Serial Device Server side (next page) with default settings.

# Connecting to a shared serial port from the serial device server


1. In **Create connection** tab choose the required connection type: Connect serial port to Serial Server Device. The name to identify this connection will be set automatically depending on the shared serial port, which participates in connection.



2. Specify the shared serial port number to connect to.



3. Also specify the remote server's IP or name, as well as TCP port, used in connection. Click **Add** button to add IP address to IP's list.




# Creating UDP Connecting

Serial to Ethernet Connector lets you establish UDP/IP connection between serial ports. UDP connection may come useful for streaming big chunks of data as well as for Mail, DNS, Finger and other services.

To create a connection, follow these instructions:

1. Switch to **Create connection** tab.
2. Specify connection name to identify this configuration. Default name is based on local serial port number, which participates in connection, and connection type in brackets.





3. Select connection type you want to create. In this case it is **Share serial port using UDP**.

4. In **Select Serial Port** field choose local serial port which will participate in connection: either add it manually, or select one from the drop-down list.
5. Tick **Create as virtual serial port** option if you would like to use virtual serial ports instead of real ones.
6. Tick **Strict baud rate emulation** checkbox if you want to enable baud rate emulation. You can find more details about our virtual serial port and baud rate emulation technologies here.
7. Specify IP address (or network name) of the remote end and port number to connect to. Make sure that the port numbers are the same at both ends and are not blocked by firewall.
8. You can also specify the port to receive the data, regardless of the port the data is sent to. It may be useful if you create UDP connection with several devices that have the same ports.
9. Finally, click **Create connection** button. Once connection is created, you can see it in Connections tree.
10. Open local serial port. You may use Windows HyperTerminal utility for this purpose. This step is necessary only if you want to verify whether the connection was created successfully.
11. Create UDP connection at the remote end. Repeat steps 1-10 listed above. Make sure that the port numbers are the same at both ends and are not blocked by firewall.
12. Now you are ready to start communication process with default settings. You can refer to Editing UDP connection section if you would like to edit a newly established connection.

# Serial to Ethernet Toolkit

## Search a serial device




1. Double click the shortcut  on the desktop.
2. Connect a serial device server to the computer and then open the **Serial to Ethernet Toolkit**.
3. Click <**Device Management**> on the left window.
4. Click <**Search**> button on the right window.
5. All the searched devices will be listed on the **Device List** when the search procedure is finished.

# Web console

This Serial server supports the remote configuration using web console on the network. To use the web console, open a web browser (eg., Internet Explorer) and type the IP address which you have set in the **Network and Sharing Center** (string example of Windows 7<sup>®</sup>, the actual string is depending on your operating system).

**Note:** Configure the IP address to 192.168.3.X where the X is between 2 and 254. To set up your computer's IP address, refer to the operating system's instruction manual.



Login the web console, and then click **Submit**. By default, the password is **admin**. To change the **Username** and **Password**, refer to **Security** chapter.

**Login**

Username

Password



# Network settings

Net Work Serial Port Advance Security

Firmware Version 3.2.14 Logout

### Network Settings

DHCP Client

Static IP Address

Static Subnet Mask

Static Default Gateway

Static DNS Server

Connection Type Port1

Connection Type Port2

Transmit Timer Port1

Transmit Timer Port2   
Please enter an integer between 10~65535 ms

Server/Client Mode Port1

Server/Client Mode Port2

Server Listening Port1

Server Listening Port2

Client Destination IP Port1

Client Destination IP Port2   
Please enter host name or IP address(e.g. gtrend-auto.com or 10.4.1.100)

Client Destination Port1

Client Destination Port2   
Please enter an integer between 1024~65535

**DHCP Client:** Enable or disable the DHCP client function. To configure the items of IP Address, Subnet Mask, Gateway and DNS Server, please select Disable.

**Connection Type:** Select a preferred communication protocol.

**Transmit Timer:** Enter a preferred packet period when transmitting serial data, the parameter is between 10~65536ms

**Server/Client Mode:** Select the preferred mode for connected serial device.

**Server Listening:** Enter a preferred parameter for listening

**Client Destination IP:** Enter the host name or IP address

**Client Destination Port:** Enter a preferred parameter for connected port, the parameter is between 1024~65535.

Once the configuration has been completed, click the **<Apply>** and then click **<Reboot>** button to restart. To restore the factory default, click **<Restore default>** button.

# Serial Port

The screenshot shows a web-based configuration interface for a device. At the top, there are tabs for 'Net Work', 'Serial Port', 'Advance', and 'Security'. The 'Serial Port' tab is active. The interface is divided into sections: 'Device Name Settings' with a 'Device Name' field containing 'FE2320'; 'Serial Settings' which includes 'PORT 1' and 'PORT 2'. Each port has a list of settings: 'Data Baud Rate' (115200), 'Data Bits' (8), 'Data Parity' (None), 'Stop Bits' (1), 'Flow Control' (Xon/Xoff), and 'Interface' (RS232 or RS422/RS485 4 wire). At the bottom, there are four buttons: 'Apply', 'Cancel', 'Restore default', and 'Reboot'.

**Data Baud Rate:** Select the data transfer rate per second.

**Data Bits:** Select a preferred data bits

**Data Parity:** Select a preferred data parity.


**Stop Bits:** Select a preferred stop bits

**Flow Control:** Select a preferred method of flow control

**Interface:** Select the interface of connected serial device.

# Advance

## Firmware upgrade



The screenshot shows a web interface for firmware upgrade. At the top, there are tabs for 'Net Work', 'Serial Port', 'Advance', and 'Security'. The 'Advance' tab is selected. In the top right corner, 'Firmware Version' is set to '3.2.14' and there is a 'Logout' link. Below the tabs, the page title is 'Firmware Upgrade Settings'. There are two input fields: 'TFTP Server IP' with the value '192.168.2.108' and 'File Name' with the value 'GW\_v3.2.14\_20120106.bin'. At the bottom, there are three buttons: 'Apply', 'Cancel', and 'FirmwareUpgrade'.

1. Enter the IP address where the firmware is saved to **TFTP Server IP**.
2. Enter the file name of the firmware. Make sure the file name you entered is matched to the file on the TFTP server.
3. Click <**Apply**>, and then click <**Firmware Upgrade**>.

## SMTP setting



The screenshot shows the 'SMTP Settings' page. It has a title 'SMTP Settings' and a dashed line separator. Below the separator, there are five input fields: 'E-mail Server Address/IP', 'From E-mail Address/IP', 'To E-mail Address 1', 'To E-mail Address 2', and 'To E-mail Address 3'. A blue text prompt reads: 'Please enter host name or IP address(e.g. gtrend-auto.com or 10'.

**E-mail Server Address/IP:** Enter the SMTP host address

**From E-mail Address/IP:** Enter the host email address

**To E-mail Address 1/2/3:** Enter the recipient email(s).

**SMTP auto warning report settings:** Enable or disable the warning options individually. Once the option has been enabled, the warning report will be sent to the email you specified when the status of option is changed.

The screenshot shows a configuration window titled "SMTP Auto Warning Report Settings". It contains four rows, each with a label and a dropdown menu:

Setting	Value
Cold Start	Disable
Authentication Failure	Disable
Local IP Address Changed	Disable
Password Changed	Disable

**SNMP Settings:** Select **Enable** to open or **Disable** to close the SNMP function.

The screenshot shows a configuration window titled "SNMP Setting". It contains the following fields and controls:

- SNMP:** A dropdown menu set to "Enable". Below it is a blue instruction: "Please clicking 'reboot' button after clicking 'apply' button".
- Community Name:** A text input field containing "public".
- Contact:** An empty text input field.
- Location:** An empty text input field.
- Trap Server:** A text input field containing "0.0.0.0".
- SNMP Auto Warning Report Settings:** A sub-section with two rows, each with a label and a dropdown menu:
  - Cold Start: Disable
  - Authentication Failure: Disable
- At the bottom, there are three buttons: "Apply", "Reboot", and "Cancel".

**SNMP Auto warning report settings:** Enable or disable the SNMP warning options individually. Once the option has been enabled, the warning report will be sent to the email you specified when the status of option is changed.

**Note:** The option of warning report is only available when the SNMP function is enabled.

Click <**Apply**>, and then click <**Firmware Upgrade**> to confirm.

# Security

Net Work Serial Port Advance Security **Security** Logout

Mikrotik WinBox Version 3.2.1.0

### Change Username Setting

New Username

### Change Password Setting

Old Password

New Password

Confirm Password

## Change the username

1. Enter the desired username to **New Username**.
2. Click <**Apply**>, and then click <**Reboot**>.


## Change the password

1. Enter the previous password to **Old Password**.
2. Enter the desired password to **New Password**.
2. Click <**Apply**>, and then click <**Reboot**>.

# Telnet console configuration

Except the **Device Server Manager** and **Web browser**, telnet is the third way to configure the server. Follow the steps below to access the server. Note that the descriptions below are using Windows Operation System platform. To configure the server through other terminal utilities, refer to instruction manuals of the manufactures.

1. Click **Start**, and then select **Run**.
2. Enter "**telnet 192.168.0.3**" ( according to the server's factory default or the IP address you have set) in the text box of **Run**, and then click **OK**.



3. The login message appears after opening the telnet. By default, both username and password are "**admin**".
4. The commands shown below are examples for you to configure the server.

4-1 To view the current IP address, type "**setip**".

```
telnet>
telnet> setip
IP address: 192.168.0.3
Ok
telnet> _
telnet> setip 192.168.0.5
Ok
telnet> _
```

4-2 To change the IP address, type "**setip 192.168.0.5**" (example). Once the command has been modified, type "saveconfig" to save the parameters into flash of server.

## Commands reference

The commands below are the references for configure the serial device server. Alternatively, you can also type "**help**" to list the commands in the telnet window.

---

help

quit

reboot

reset

Usage: passwd

    Old Password:

    New Password:

    Re-enter New Password:

Usage: username <user name>

Usage: ipconfig

Usage: setip <ip addr>

Usage: setmask <netmask>

Usage: setgateway <ip addr>

Usage: setdns <ip addr>

Usage: transmitimer <time>

    <time>: time in ms

Usage: dhcpclient <status>

    <status>: 0: disable   1: enable

Usage: connectype <protocol>

    <protocol>: 0: TCP   1: UDP

Usage: setmode <mode>

    <mode>: 0: SERVER   1: CLIENT

Usage: setsrvport <port>

Usage: setdstport <port>

Usage: setdsthn <Host name/IP>

Usage: connstatus

Usage: fwversion <FW Version:>



Usage: devicename <device name>

Usage: serialport <baud rate> <data bits> <parity> <stop bits> <flow ctrl>

<baud rate>: 0: 921600 5: 9600

1: 115200 6: 4800

2: 57600 7: 2400

3: 38400 8: 1200

4: 19200

<data bits>: 0: 5 2: 7

1: 6 3: 8

<parity>: 0: Odd 2: None

1: Even

<stop bits>: 0: 1 1: 1.5 2: 2

<flow ctrl>: 0: Xon/Xoff 2: None

1: Hardware

Usage: interface

<mode>: 0: RS232 or RS422/RS485 4 wire

<mode>: 1: RS485 2 wire

Usage: setems <e-mail server address/ip>

Usage: setemf <e-mail address>

Usage: setemt1 <e-mail address>

Usage: setemt2 <e-mail address>

Usage: setemt3 <e-mail address>

Usage: emconfig

Get E-MAIL Configuration

Usage: setsnmp <mode>

<mode> : 0: Disable 1: Enable

Usage: snmpcom <name>

<name> : SNMP Community name

Usage: snmpcont <name>

<name> : SNMP Contact name

Usage: snmploc <name>

<name> : SNMP Location name

Usage: snmpconfig  
    Get SNMP Configuration

Usage: trapsrvip <ip addr>  
    <ip addr> : Set Trap server IP

Usage: settrapcoldstart <mode>  
    <mode> : 0: Disable 1: Enable

Usage: settrapauthfail <mode>  
    <mode> : 0: Disable 1: Enable

Usage: setaw <Cold Start> <Authentication Failure> <Local IP  
    Address Changed> <Password Changed>  
    <Cold Start>:            0: Disable  1: Enable  
    <Authentication Failure>:  0: Disable  1: Enable  
    <Local IP Address Changed>:  0: Disable  1: Enable  
    <Password Changed>:        0: Disable  1: Enable

Usage: saveconfig

Usage: filename <file name>

Usage: tftpsrv <ip addr>

Usage: dlfirmware


Usage: setEEP <HEX RegStartAddr> <HEX Byte 0> <HEX Byte  
    1>...<HEX Byte N>

Usage: dbgmsg <mode>  
    <mode>: 0: Disable  1: Enable


# Connection diagram

Once the software setup has been completed, you can connect and operate the RS-422/485 device through Ethernet Network.

## 1-Port RS-422/485 serial device server



## 2-Port RS-422/485 serial device server



# Regulatory compliance

## FCC conditions

This equipment has been tested and found to comply with Part 15 Class B of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received and include interference that may cause undesired operation.

## CE

This equipment is in compliance with the requirements of the following regulations: EN 55 022: CLASS B

## WEEE Information

For EU (European Union) member users: According to the WEEE (Waste electrical and electronic equipment) Directive, do not dispose of this product as household waste or commercial waste. Waste electrical and electronic equipment should be appropriately collected and recycled as required by practices established for your country. For information on recycling of this product, please contact your local authorities, your household waste disposal service or the shop where you purchased the product.



RS-422/485 Serial Device Server  
User's Manual



1230 v1