

# **Firmware Update Guideline**

## **CDPS-41SQ**

Date: 2013/3/30

Written by: Air Chou

Version: 1.0

1. Use USB cable to connect CDPS-41SQ and PC on Windows OS.  
(Don't Plug the power supply)
2. Plug the power supply.
3. Wait a folder pop up on Windows OS.
4. Put the latest binary firmware into the folder.
5. Remove the USB cable
6. Unplug then plug the power supply.
7. The firmware update is done.